
Introduction to Computational Neuroscience Practice II: Data Analysis - Continuous Data

Ilya Kuzovkin, Raul Vicente February 20, 2014

This is how usual EEG recording of one channel looks like:



On the x axis there is time, on the y axis strength of the recorded signal in μ V. The dashed line at the time point x = 1000 is the moment when the *stimulus* (picture) was shown to the test subject.

Exercise 1: Event Related Potential (ERP) (0.5pt)

By looking at the plot above one cannot say that showing the stimulus had any considerable effect on the test subject. It seems that there is an increase starting at the time point 1200 and ending at the time point 1500, but that can be a random event, which is not related to the stimulus.

In such studies the way to go is to conduct the same experiment several times and then average the results. In this way the response, if it is there, will reveal itself much more clearly.


In the data folder you have file erptrials.csv. One row is one trial recorded for 2 seconds with sampling rate of 1000 Hz. The stimulus was shown at the time point 1000 (1 second). There are 79 trials in this file. Your task is to plot an average of all 79 trials and see whether there is a clear ERP response or not.

Exercise 2: Correlation (0.5pt)

Sometimes you might want to know how much two signals are related to each other. For example you can look at the correlation between two channels. If you find out that two distant channels are correlated (or correlated with a time shift), then you might want to find an explanation for that phenomena. And this explanation might reveal something interesting about how our brain works.

In the file multichannel.txt you will find tab separated values. Each row represents one electrode and contains 1.5 seconds of data (sampling rate is 512). The electrode names are (in the

same order as they appear in the file): Fp1, AF3, F7, F3, FC1, FC5, C3, CP1, CP5, P7, P3, Pz, P03, O1, Oz, O2, P04, P4, P8, CP6, CP2, C4, FC6, FC2, F4, F8, AF4, Fp2, Fz, Cz. On the following figure you can see how these electrodes were located on the test subject's head during this particular experiment.



Your task is to calculate correlation between the channels AF3 and F3 and explain why the number that you get makes sense.

Hint. In Matlab you can use corr function.

Exercise 3*: Graph of correlations (0.5pt)

Now compute pairwise correlations between all channels. Create a graph of correlations, where

- Nodes are channels.
- Two nodes are connected if correlation between corresponding channels is ≥ 0.9 .

Plot correlations as a heatmap. Do you observe something interesting from graph or from the plot?

Hint. In Matlab use image or surf function for plotting.

Exercise 4: Frequency Analysis (1pt)

The most popular operation that you can do with continuous brain data is converting it from the *time domain* to the *frequency domain*. Due to the fact that any function can be represented as a sum of sinusoids we can decompose our signal into such sinusoids and observe from which frequency components it consists. In terms of the brain data such transformation makes particular sense, because of the *brain rhythms* – different frequencies of the firings of the neurons are related to the different kinds of mental activity¹.

In this exercise we will see how *alpha wave* emerges when the test subject's eyes are closed. In the data folder you can find two files: eyes_open.csv and eyes_closed.csv. The data is recorded from the channel Pz. One row contains 4 seconds of the signal, sampling rate is 512. Each file has 15 recordings.

¹http://en.wikipedia.org/wiki/Electroencephalography#Wave_patterns

Your task is to perform Fourier analysis on both datasets and compare the results. Do it as follows:


- 1. Plot some of the signals just to see how they look like.
- 2. For each recorded signal (2048 data points):
 - (a) Use fft(signal) to compute power spectrum of this signal. You will get a vector of complex numbers.
 - (b) Use abs(result_of_fft) to obtain the magnitude².
- 3. Sum together 15 power spectrum distributions, that you got from the previous step.
- 4. And divide the resulting vector by 15 to obtain the average.
- 5. Plot it. You will see that the right part of the graph is mirror image of the left part. Discard the right part.
- 6. Your x axis goes from 1 to 1024, which does not correspond to actual frequencies. Compute correct x axis as follows:

7. And plot it again

```
plot(xaxis, powers);
```

Now your axis goes from 0 to 256 (or 512) with step of 4, which corresponds to the frequency range pow function produced.

After making the plot more beautiful and focusing on the range from 0 to 30 Hz you should obtain the result that looks something like this:



²http://www.mathworks.se/help/matlab/ref/abs.html

Exercise 5: Discrete Fourier Transform (DFT) (1pt)

Now let us have a look on what happens behind the scenes when you call the fft^3 function. Fourier transform is possible because, as we mentioned before, any function can be represented as a sum of sinusoidal functions of different frequencies and amplitudes. If you have some variable changing over time you can transform this data from the time domain (time on the x axis and the value of the variable on the y axis) to the frequency domain (frequency on the x axis and it's power on the y axis) to see if there is any periodicity in the changes of that variable.

Transformation is defined both for continuous and discrete data. On practice we mostly work with a discrete signal and therefore we use Discrete Fourier Transform (DFT). The equation for the discrete transform is

$$X_f = \sum_{t=0}^{N-1} x_t e^{-i2\pi f \frac{t}{N}}$$

where


- f is the frequency of the component, contribution of which you are trying to estimate.
- X_f is a complex number, that encodes both amplitude and phase of the sinusoidal component.
- x_t is a value of your signal at the time point t.
- N is the total number of time points.

Let us say that you would like to know contribution of sinusoidal components of frequencies from 0 to 100 Hz. Then you should apply this equation 101 times. As a result you will get 101 complex numbers. To extract amplitude from these numbers use the following equation on each of them:

$$A_f = \frac{\sqrt{\operatorname{Re}(X_f)^2 + \operatorname{Im}(X_f)^2}}{2N}$$

Now you have all the contributions and you have completed Discrete Fourier Transform of your signal. For example if 7th number is "25" then it means that the amplitude of the sinusoidal component with frequency 7 Hz is 25.

Here you see a curve, that is a sum of three sinusoids. Your task is to apply DFT and find out frequencies and amplitudes of those components. You can find data points for this curve in the file curve.csv.



³Actually Fast Fourier Transform (FFT) is a specific algorithm. In this exercise we do not analyse that, but rather look at the equations, which FFT solves in his own mysterious way.

Exercise 6*: Epilepsy (0.5pt)


In the folder data/epilepsy you have two data files: sz4_pre.dat and sz4_ict.dat. This data was recorded using ECoG⁴ array. The file with the suffix _pre is recorded before the seizure and the _ict file is recorded during the epilepsy seizure. Read the README.txt file for the description of the data. Your task is to perform Fourier analysis on both files and see how brain activity changes during the epilepsy seizure.

Hint. Reuse the code from the exercise 4.

Hint. The data has readings from the 76 electrodes, take FT of each of them and then average.

Exercise 7: Nyquist theorem (0.5pt)

What does Nyquist theorem say? What does it mean? What are the implications? What does this picture illustrate?



Prepare to present and explain the theorem to your fellow students.

Please submit a pdf report with the answers to the questions, plots and comments about your solutions. Also submit the code for the programming exercise(s). Pack those into the zip archive and upload to the course web page.

⁴http://en.wikipedia.org/wiki/Electrocorticography